


# sd-space drawer

Over time IKEA BILLY has had different shelf supports. I call them 'A' and 'B' shelf supports.


**1**



Older      Newer      A

'A' shelf supports. These have no lip (old and new).


**2**



B

'B' shelf supports. These have a small lip (older).


**3**



A

'A' - The SD sits closer to BILLY's side.


**4**



B

'B' - The SD sits around 11 mm away from BILLY's side.

**5** Users with 'B' supports can use the 'A' setting by using the alternative shelf supports provided.




B to A

**6**



Manual covers both fittings.

**7**



Tip - Shelves may move when using **alternative supports**. Fill the chosen side shelf holes with mastic or 'Blu-tack' to stop the shelf moving.

This works very well.

